



Note! Add #5 Bar to Throat of all Inlets.