



NOTE: Add #5 Bar to throat of all inlets.