



CALL BEFORE
YOU DIG!
1-800-DIG-RITE

E:\DWC\AI1000PLUS\11282C-Perucreek\CONSTRUCTION\MODOT-INTERCHANGE\11282CMODOT-UTILITY.dwg, PROFILES-7, 7/28/2004 11:11:33 AM, Sta 36 SWR