



NOTE! Add #5 Bar to Throat of All Inlets.