




**ACCESSIBLE SYMBOL**  
N.T.S. CS19




**ACCESSIBLE RAMP DETAIL**  
N.T.S. CS29




**TYPICAL PAVEMENT MARKINGS**  
N.T.S. CS42




**DIRECTIONAL TURN**  
N.T.S.




**TBO PAVEMENT MARKINGS  
EXIT W/ ARROW DETAIL**  
NO SCALE CS37




**TYPICAL DUMPSTER LAYOUT W/SCREENING**  
NO SCALE




**PAVED SURFACE BASE  
U-CHANNEL SIGN POST**  
N.T.S. CS61



**VEGETATED SURFACE BASE**




**DIRECTIONAL ARROW DETAIL**  
N.T.S. CS09




**CART CORRAL DETAIL @ 90° PARKING**  
N.T.S. CS05


ASSEMBLY INSTRUCTIONS:  
1. PLACE BOTTOM PLATES APPROXIMATELY SEVEN FEET APART.  
2. ASSEMBLE SIDE RAILS TO SIGN FRAME WITH FOUR BOLTS IN LOCATIONS SHOWN.  
3. SLIP SIDE RAILS INTO BOTTOM PLATES.  
4. INSTALL IN LOCATIONS SHOWN ON SITE PLAN.



**90° PARKING DETAIL**  
N.T.S. CS20




**PARKING LOT  
SIGN POST DETAIL**  
NO SCALE CS22



**STOP SIGN**  
N.T.S. CS12




**NO TRUCKS SIGN**  
N.T.S. CS50




**TRUCK ROUTE SIGN**  
N.T.S. CS51




**PEDESTRIAN CROSSING SIGN**  
N.T.S. CS26




**PARKING SIGN**  
N.T.S. CS12




**PIPE BOLLARD DETAIL**  
NO SCALE CS27



**TBO PAVEMENT MARKINGS  
ENTER W/ ARROW DETAIL**  
N.T.S. CS36



**TYPE 'D' CONCRETE (EXTRUDED) CURB**  
N.T.S. CS57



**AISSLE SIGN DETAIL**  
N.T.S. CS01

