


METHOD OF HOLDING DUCT IN PLACE WHEN POURING CONCRETE  
 WIRE SUPPORTS TO OCCUR AT 4'-0" INTERVALS FOR DUCTS UP TO 6" INCLUDING  
 10" DIA. - 12" DIA. INTERVALS FOR DUCTS 12" DIA. & OVER. SUPPORTS ALSO  
 TO OCCUR AT JOINTS & AT ANY OTHER NECESSARY POINT SO AS TO  
 INSURE A RIGID DUCT SYSTEM WHEN POURING CONCRETE.

**INSTALLATION OF UNDERGROUND DUCT**  
 NO SCALE

CHAPEL BASEMENT & FOUNDATION PLAN  
 SCALE 1/8" = 1'-0"

- ① NOTE-1 CUT OPENINGS IN EXISTING WALLS FOR PIPING & DUCTWORK. PATCHING BY GEN. CONTRACTOR.
- ② NOTE-2 HEATING CONTRACTOR SHALL CORE DRILL ON EACH SIDE OF EACH OPENING AND CHISEL THE REMAINDER. CONTRACTOR SHALL BE VERY CAREFUL NOT TO CRACK ADJACENT TILES.



DATE:	ADDITION TO ST. MARY'S INSTITUTE OF FALLON, MO.	
DRAWN BY:	C.F.	
JOB NO.:	A.P. & ARTHUR STAUDER, ARCHITECTS 3606 SOUTH GRAND BLVD. ST. LOUIS 18, MISSOURI	SHEET <b>M-7</b>
REVISIONS:	PAUL LONDE & ASSOC. CONSULTING ENGINEERS	